



Cast Iron Children's Bench

The Weston® Collection

Thank you for your purchase of this bench in the **Weston® Collection** of outdoor benches, swings and accessories. Every step has been taken to make this the best looking longest lasting bench in the market today. Our 3-step wood sealing process and powder coat iron finish give you a product to enjoy for years to come. The growing Weston Collection can be seen at www.paintedskydesigns.com

Assembly Instructions

Step 1. Holding each cast iron leg frame upright on a flat surface and parallel to each other, align the four holes in the wood frame of the backrest with the leg frame holes. *(Illustration 1)* Insert bolts from the front and attach nuts. Turn the nuts snug, but not tight.

Step 2. Position and bolt each of the wooden seat slats to the frame making sure that all slats have the counter sunk holes facing up. *(Illustration 2)* Start with the wooden seat slat that has the front edge rounded. Position this at the front and work your way back. Again, do not tighten the nuts yet.

Step 3. You should now have all 12 bolts lightly secured. With your assistant holding the leg frames at a straight 90° angle to the ground, tighten the nuts, starting with the backrest. *(Illustration 3)* Continue until **all** nuts and bolts **have been tightened**.

Step 4. Turn the assembled bench upside down, taking care not to scratch the topside. Place the support bracket in the center of the leg frame section and mark with a pencil. *(Illustration 4)* Attach with the provided wood screws. Note: the brackets can be easily hand formed to fit the exact contour of the seat if necessary.



Parts List

Cast iron leg frame	2
Cast iron backrest/wood frame	1
Wooden seat slats	4
Seat bracket	1
Mounting hardware	
Nuts/bolts	12
Wood screws	4

Tools needed:

- Large flat slot screwdriver
- Medium phillips screwdriver
- 10 mm wrench

Note: While the bench can be assembled by one person, a second set of hands will help considerably.

